BETTA SE

Here are some important guidelines to follow when using the Betta SE robotic skimmer.

Do not swim while the Betta is operating in the pool: It is crucial not to swim when the Betta is in use. Remove it from the water and keep it in a cool, shaded place while the pool is being used.

Keep the Betta out of reach of children: The Betta is not a toy. Make sure to keep it out of reach of children to prevent any accidents.

The Betta with other cleaning devices: The Betta should not be used when other pool cleaning devices are already in operation in the water.

Keep the Betta in the water during the swimming season: During the swimming season, keep the Betta in the pool at all times, except when it is in use or when the unit requires cleaning or maintenance.

Avoid damage by leaving it in a suitable location: The Betta reacts poorly to hot and dry places if it is left outside of the pool unattended, this could cause serious damage to the unit.

Pressure washer: Avoid cleaning the Betta with a pressure washer, as this could damage the unit.

Fall / winter and below 20 degrees Celsius: In cold weather and off-season, the solar battery may experience charging failures. This is due to the particular angle of the sun's rays. The solution is to take the Betta out of the water and orient it towards the sun for an entire day at a 45-degree angle. Then put it back in the water.